

WHANGAREI RADIO CALLS

WHEN READY TO TAXI

WHANGAREI TRAFFIC

[Callsign]

Example...

HANGAR 10

TAXIING TO THE APRON

AFTER RUN UP AND WHEN READY TO TAXI

WHANGAREI TRAFFIC

[Callsign]

Example...

MAIN APRON

TAXIING APRON HOLDING POINT 24 or GRASS HOLDING POINT 24 or HOLDING POINT 06

WHEN READY TO LINE UP

WHANGAREI TRAFFIC

[Callsign]

ENTERING AND BACKTRACKING RUNWAY 24 or 06 TO LINE UP

WHEN ROLLING

WHANGAREI TRAFFIC

[Callsign]

Example...

ROLLING RUNWAY 24 or 06

VACATING TO (RUAKAKA OR WHEREVER YOU ARE GOING)

CLIMBING TO 2500 FEET (OR WHATEVER ALTITUDE)

POSTION REPORTS EVERY 5 MINUTES IN THE WHANGAREI MBZ

WHANGAREI TRAFFIC

[Callsign]

Example...

6 MILES TO THE SOUTH EAST

2500 FEET

REMAINING IN THE AREA

INBOUND FOR LANDING

WHANGAREI TRAFFIC

[Callsign]

Example...

5 MILES TO THE SOUTH EAST

1600 FEET

INBOUND FOR LANDING

JOINING OVERHEAD/ LEFT BASE RUNWAY 24/ DOWNWIND RUNWAY 06 ETC

ON DOWNWIND

WHANGAREI TRAFFIC

[Callsign]

DOWNWIND RUNWAY 24 or 06

FULL STOP or TOUCH AND GO

ON FINAL

WHANGAREI TRAFFIC

[Callsign]
FINAL RUNWAY 24 or 06
FULL STOP or TOUCH AND GO